



Painting on ceramics & vertical ceramic tile



1L TSP All Purpose Spray Cleaner (Home Hardware Number 1620-198)

Sand with 120 to 150 grit sand paper to improve adhesion. Clean surface with TSP Plus or Natura Safe Prep, rinse well if using TSP Plus. Let dry.

Primer



3.7L White Interior/Exterior STICK iT Latex Primer (Home Hardware Number 1850-793)

Apply 1 coat of Acryl-Lok Stick iT or Oil Primer and then 2 coats of paint.

Topcoat



3.64L White Base Suede Finish Interior Latex Paint (Home Hardware Number 1858-617)

Designer Series, Natura, or Signature Series paint. Allow to cure for 10 days to 2 weeks before using surfaces if in a damp, wet area. Do not apply on tile floors or ceramic tile in showers or tubs.

The instructions in this list are provided by Beauti-Tone.