



# Painting on glass with a chalk look

## Surface Prep

Start with a clean , dry surface. Lightly sand.

## Primer

No primer is needed for this.

# Topcoat



Joint Compound (Home Hardware Number 1625-860)



80mL EZ Patch and Fill Drywall Compound (Home Hardware Number 1627-721)



3.64L White Base Matte Finish Interior Latex Paint (Home Hardware Number 1858-626)

Add up to 1/2 cut of Drywall Compound to 1 liter of Designer Series Matte and mix well. To save time and money you can squeeze a in a tube EZ Patch (Home Hardware Number 1627-721).

The instructions in this list are provided by Beauti-Tone.